


AKL 730

GB IE

PRODUCT DESCRIPTION SHEET



1. Rapid hotplate Ø 180 - 2000 W
2. Normal hotplate Ø 145 - 1000 W
3. Normal hotplate Ø 180 - 1500 W
4. Normal hotplate Ø 145 - 1000 W
5. Rapid hotplate control knob Ø 180
6. Normal hotplate control knob Ø 145
7. Normal hotplate control knob Ø 180
8. Normal hotplate control knob Ø 145
9. Hotplate operation control lamp




Operation of electric hotplates






- Set the knob to one of positions 1-6, which correspond to different temperatures.
- To switch off the hotplate, set the knob to position "0".

5019 519 60031/A

DIMENSIONS OF COOKTOP AND WORKTOP



NOTE: In case of installation of a hood above the cooktop, please refer to the hood instructions for the correct distance.

SUPPLY VOLTAGE	CONDUCTORS: NUMBER AND SIZE	ELECTRICAL CONNECTION
230 V ~ + 	3 x 2.5 mm ²	<div>1 2 3 </div> <div>  </div> <div>L N</div>